



# Motorola C168 SIM Card Replacement

Instructs user on how to remove and replace the SIM card.

Written By: Dan Baifus



## Step 1 — Battery



- Turn the phone so its back is facing you.
- Press the release button on the back cover, while simultaneously pulling the cover down.
- Remove the back cover.

## Step 2



- Pinch the sides of the bottom of the battery and pull upward.

## Step 3 — SIM Card



- Press and slide the SIM card down.
- Remove the SIM card.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-02 01:41:35 AM.